




TECHNOLOGY CO.,LT

YY-W201

| Item | Part Name | Q'TY | Remark |
|------|-----------------|------|---------------|
| 1. | Top Cover 1 | 1 | 0201-W2081-A |
| 2. | Chassis | 2 | 0203-W2101-A |
| 3. | Power Suport | 1 | 0211-W2102-A |
| 4. | Spring (EMI) | 52 | 0215-W2011-B |
| 5. | 120mm Fan | 1 | 0612-00501-A |
| 6. | Back Window | 1 | 0209-540B1-A |
| 7. | Back Plate | 1 | 0222-W2101-A |
| 8. | MB Palet Add | 1 | 0211-W2101-A |
| 9. | 60mm Fan Cover | 2 | 0219-A10B1-A |
| 10. | Slot Shield | 1 | 5506-54001-A |
| 11. | Slot Bracket | 7 | 0207-00061-A |
| 12. | Screw #6-32 | 7 | 5401-54051-A |
| 13. | MB Plane | 1 | 0208-W2101-A |
| 14. | Left Frame | 1 | 0206-W2101-A |
| 15. | Front Plate | 1 | 0225-W2101-A |
| 16. | Right Guide | 8 | 0214-W2082-A |
| 17. | FDD Braket | 1 | 5532-00000-A |
| 18. | Left Guide | 8 | 0214-W2081-A |
| 19. | Right frame | 1 | 0206-W2102-A |
| 20. | L Cover | 1 | 0221-W2084-A |
| 21. | 5.25" EMI Cover | 7 | 0221-W2082-A |
| 22. | EMI Cover | 1 | 0221-W2061-A |
| 23. | Buzzer | 1 | 0503-00701-A |
| 24. | Buzzer holder | 1 | 0316-00001-A |
| 25. | Hooker | 6 | 5512-00001-A |
| 26. | Panel Led | 1 | 0306-W2XX1-A |
| 27. | Screw M3-HEX8MM | 4 | 5401-15161-A |
| 28. | Front Panel | 1 | 0301-W20101-A |
| 29. | Reset Knob | 1 | 0305-W2010-A |
| 30. | Power Knob | 1 | 0303-W2010-A |
| 31. | 5.25" Cover | 7 | 0311-W1010-A |
| 32. | Screw | 6 | 5401-31083-A |
| 33. | Filter | 1 | 5501-W2002-A |
| 34. | C Pin | 2 | 0385-W2001-A |
| 35. | Door Led | 1 | 0306-W2011-A |
| 36. | Door | 1 | 0308-W2012-A |
| 37. | Power Spring | 1 | 5407-05101-A |
| 38. | Lock kit | 1 | 0009-W2001-A |
| 39. | Led Housing | 6 | 0387-W1011-A |
| 40. | PIN GU | 1 | 0381-W2XX1-A |
| 41. | led_lens | 1 | 0403-W2011-A |
| 42. | Switch Holders | 2 | 0316-W2XX1-A |
| 43. | Power Switch | 1 | 0401-00701-A |
| 44. | Reset Switch | 1 | 0402-00701-A |
| 45. | Top Cover 2 | 1 | 0201-W2082-A |
| 46. | Foot | 4 | 5703-00002-A |
| 47. | Side Cover | 2 | 1202-W2081-A |
| 48. | Handle | 1 | 5507-W2001-A |
| 49. | ATX I/O Shield | 1 | 5005-00003 |
| 50. | Holder | 2 | 0211-W2121-A |
| 51. | Foot Holder | 4 | 0314-W2002-A |
| 52. | Hdd bracket | 7 | 5521-W1A01-B |
| 53. | USB bracket | 1 | 0211-W2103-A |
| 54. | 60mm Fan | 1 | 0606-34501 |

● Optional accessory






TECHNOLOGY CO.,LT

YY-W202

| Item | Part Name | QTY | Remark |
|------|--------------------|-----|------------|
| 1. | COVER TOP | 1 | 0201-W2081 |
| 2. | CHSAAIS | 1 | 0001-W2XX2 |
| 3. | PSU TRANSFER PLATE | 1 | 0211-W2102 |
| 4. | 120mm FAN | 1 | 0612-R0702 |
| 5. | MB PALET ADD | 1 | 0211-W2101 |
| 6. | 60mm FAN COVER | 2 | 0219-A1081 |
| 7. | SLOT SHIELD | 1 | 5506-54001 |
| 8. | SLOT BRACKET | 7 | 0207-00061 |
| 9. | SCREW #6-32 | 7 | 5401-54051 |
| 10. | RIGHT SLIDE | 8 | 0214-W2082 |
| 11. | LEFT SLIDE | 8 | 0214-W2081 |
| 12. | FDD BRACKET | 1 | 0211-W2081 |
| 13. | L COVER | 1 | 0221-W2084 |
| 14. | 5.25" EMI COVER | 7 | 0221-W2082 |
| 15. | EMI COVER | 1 | 0221-W2081 |
| 16. | BUZZER | 1 | 0503-00701 |
| 17. | BUZZER HOLDER | 1 | 0316-00001 |
| 18. | SCREW | 6 | 5401-31062 |
| 19. | HOOKERS | 6 | 5512-00001 |
| 20. | SCREW #6-32 | 4 | 5401-15161 |
| 21. | PANEL ASSY | 1 | 0002-W202A |
| 22. | SCREW | 6 | 5401-31063 |
| 23. | FILTER | 1 | 5501-W2002 |
| 24. | C PIN | 2 | 0385-W2001 |
| 25. | DOOR | 1 | 0308-W2020 |
| 26. | KEY LOCK | 1 | 0009-W2001 |
| 27. | LED HOUSING | 6 | 0387-W1011 |
| 28. | PIN GU | 1 | 0381-W2XX1 |
| 29. | LED CABLE | 1 | 0403-W2E01 |
| 30. | SWITCH HOLDER | 2 | 0316-W2XX1 |
| 31. | POWER SWITCH | 1 | 0401-00701 |
| 32. | RESET SWITCH | 1 | 0402-00701 |
| 33. | COVER DOWN | 1 | 0201-W2082 |
| 34. | FOOT | 4 | 5703-00002 |
| 35. | SIDE COVER | 2 | 0202-W2081 |
| 36. | HANDLE | 1 | 5507-W2001 |
| 37. | HOLDER | 2 | 0211-W2121 |
| 38. | FOOT HOLDER | 4 | 0314-W2002 |
| 39. | HDD BRACKET | 1 | 5521-W1A01 |
| 40. | USB BRACKET | 1 | 0211-W2103 |
| 41. | 60mm FAN | 1 | 0606-34501 |

● Optional accessory





TECHNOLOGY CO.,LT

YY-W203

| Item | Part Name | QTY | Remark |
|------|---------------------|-----|------------|
| 1. | COVER_TOP | 1 | 0201-W2081 |
| 2. | CHASSIS | 1 | 0001-W2XX2 |
| 3. | PSU TRANSFER PLATE | 1 | 0211-W2102 |
| 4. | 120MM FAN | 1 | 0612-R0702 |
| 5. | MB PALET ADD | 1 | 0211-W2101 |
| 6. | 60mm Fan Cover | 2 | 0219-A1081 |
| 7. | SLOT SHIELD | 1 | 5506-54001 |
| 8. | SLOT BRACKET | 7 | 0207-00061 |
| 9. | SCREW #6-32 | 7 | 5401-54051 |
| 10. | RIGHT SLIDE | 8 | 0214-W2082 |
| 11. | FDD BRACKET | 1 | 0211-W2081 |
| 12. | LEFT SLIDE | 8 | 0214-W2081 |
| 13. | L COVER | 1 | 0221-W2064 |
| 14. | 5.25" EMI COVER | 7 | 0221-W2062 |
| 15. | EMI COVER | 1 | 0221-W2061 |
| 16. | BUZZER | 1 | 0503-00701 |
| 17. | BUZZER HOLDER | 1 | 0316-00001 |
| 18. | SCREW | 6 | 5401-31062 |
| 19. | HOOKERS | 6 | 5512-00001 |
| 20. | SCREW #6-32 | 4 | 5401-15161 |
| 21. | PANEL ASSY | 1 | 0002-W203A |
| 22. | SCREW | 6 | 5401-31063 |
| 23. | FILTER | 1 | 5501-W2002 |
| 24. | C PIN | 2 | 0385-W2001 |
| 25. | DOOR | 1 | 0508-W2031 |
| 26. | KEY LOCK | 1 | 0009-W2001 |
| 27. | LED HOUSING | 6 | 0387-W1011 |
| 28. | MOUNTING PURSE LOCK | 1 | 0381-W2XX1 |
| 29. | LED CABLE | 1 | 0403-W2E01 |
| 30. | SWITCH HOLDER | 2 | 0316-W2XX1 |
| 31. | POWER SWITCH | 1 | 0401-00701 |
| 32. | RESET SWITCH | 1 | 0402-00701 |
| 33. | COVER_DOWN | 1 | 0201-W2082 |
| 34. | FOOT | 4 | 5703-00002 |
| 35. | SIDE COVER | 2 | 0202-W2081 |
| 36. | HANDLE | 1 | 5507-W2001 |
| 37. | FOOT HOLDER | 4 | 0314-W2002 |
| 38. | HDD BRACKET | 7 | 0211-W2082 |
| 39. | USB BRACKET | 1 | 0211-W2103 |
| 40. | 60MM FAN | 1 | 0606-34501 |

● Optional accessory

